

ARVETI4.0 –
Project partner:



IES POLITECNICO de VIGO

<p>LTTA2: Examples of the industrial applications of mixed-reality glasses:</p> <p>Creating an instruction for Dynamic 365 Guides on Microsoft HoloLens2</p>	
--	--

TASK: Create an instruction in Dynamics 365 Guides for operating the cream bottler

Materials: DAK-S bottler, HoloLens2, Laptop, Dynamic 365 Guides, Pictures

Instructions:

I. Create steps in Dynamics 365 Guides and add pictures

- ❖ Use the separately instructions, how to make steps in Dynamic 365 Guides.
- ❖ Use the steps 1 to 5 below and the prepared pictures (you find them in the “Bibliothek” in Dynamics 365 Guides)



Step 1	Switch the „Anlage Ein" button to turn on the system (picture 1).
Step 2	Select on „Anlage” ,the automatic mode (Auto) (picture 2).
Step 3	Turn the button "Automatik" to „Ein" (picture 3)
Step 4	The bottler runs now in the desired automatic mode.
Step 5	To stop the bottler you have to turn the automatic button to „Aus" (picture 4).

Need some help?

Ask our team!



II. Set up and activate the cream bottler using the HoloLens 2



The European Commission's support or the production of this publication does not constitute an endorsement of the contents, which reflect the views only of the authors, and the Commission cannot be held responsible for any use which may be made of the information contained therein.